



Knob installation information:



Outside knob has no hole in the sleeve (prevents unauthorized removal). To assemble- slip knob over shank and rotate knob until the knob catch clicks in place and retains knob



Inside knob has a hole in the sleeve for removing knob. To assemble- slip knob over shank and rotate knob until the knob catch clicks in place and retains knob. Install inside knob after trim has been mounted on the door.

To remove- line up hole in sleeve with the knob catch- depress knob catch and slip off knob.